Knife Sharpening Machine BK 81, BK 81-S

Version: 14.07.2021

Page 1 of 39

Operating Instructions

Original Operating Instructions for the NEWROX BK 81, BK 81-S Knife Sharpening Machine

Keep these Operating Instructions for use later!



It is essential that users read and observe the Operating Instructions!

NEWROX

Manufacturer



Authorised Agent

Paul Schöndorf Metallwaren GmbH Am Untergrün 4 79232 March- Buchheim

Tel.: +49 7665 95914 Fax: +49 7665 95915 E-Mail: info@paulschoendorf.de

Knife Sharpening Machine BK 81, BK 81-S

Version: 14.07.2021

Page 2 of 39

NEWROX

Table of contents

Section	Content	Page
	Cover	1
	Table of contents	2+3
1.0	Explanation of the layout of the Operating Instructions	4+5
1.1	Foreword	6
1.2	Declaration of conformity	7
2.0	Scope of supply	8
2.1	Accessories	8
3.0	Safety instructions before commissioning	9
3.1	Safety concept	10
3.2	What to do in the event of an accident	10
3.3	Hazard points and types of hazard	11-13
3.4	Intended use	14-15
3.5	Improper use	15
4.0	Requirements of the operating personnel	16
5.0	Technical data of the Knife Sharpening Machine	17
6.0	Description and function of the BK91 Knife Sharpening Machine	18
6.1	Description of the machine	18
6.2	Purpose of the machine	18
7.0	Transport	19
8.0	Installation and initial commissioning	20
8.1	Requirements of the installation location	20
8.2	Cleaning after installation	20
9.0	Assembly and commissioning	21
9.1	Control elements	21
10.0	Handling	22
10.1	Grinding and polishing procedure	22-26
10.2	Instructions for use	27
11.0	Faults and fault rectification	27
12.0	Maintenance, repairs, cleaning and care	28
12.1	Maintenance personnel (qualification and authorisation)	28
12.2	Safety instructions for repair work	28
12.3	Instructions and work instructions	29
12.4	Cleaning and care	29

Knife Sharpening Machine BK 81, BK 81-S

NEWROX

Version: 14.07.2021

Page 3 of 39

Section	Content	Page
12.5 12.6 12.7 12.8 12.9	Instructions for changing grinding wheels and polishing discs Maintenance and repair work Testing, test report Maintenance and repair procedure Drawings and diagrams	30 31 31+32 33 34-38
13.0	Instructions for disposal	39
14.0	List of drawings and diagrams supplied	39
15.0	Index of illustrations	39
16.0	Copyright	39

Knife Sharpening Machine BK 81, BK 81-S


Version: 14.07.2021

Page 4 of 39

NEWROX

1.0 Explanation of the layout of the Operating Instructions

Mandatory signs





Wear protective goggles!



Disconnect the mains plug!



Other mandatory instructions!

Warning signs



Caution!

Risk of trapping and crushing injuries to fingers from rotating discs

> Do not touch or grasp rotating discs



Caution!


Danger from electric voltage

Knife Sharpening Machine BK 81, BK 81-S

Version: 14.07.2021

Page 5 of 39

Warning signs



> Adjust guard and knife rest so that the grinding wheel or polishing disc runs freely

NEWROX



Caution!

Various hazards

Prohibitory signs



Forbidden!

Do not wash the machine with a water spray or jet!

Instructions

INSTRUCTION Hints for the user and other important information and instructions

Other signs

- > Instructions are always indicated with an arrow
- 1) Lists are always indicated with a number in a single bracket

Knife Sharpening Machine BK 81, BK 81-S

Version: 14.07.2021

Page 6 of 39

1.1 Foreword

These Operating Instructions apply to the BK 81, BK 81-S Knife Sharpening Machine for grinding knives in catering operations, and meat and foodstuffs processing. The Knife Sharpening Machine has been conceived, designed and constructed by Newrox AG, CH-4147 Aesch and is marketed in the EU by this company. The Knife Sharpening Machine is brought to the market in compliance with the requirements of the Machinery Directive and current directives, standards and regulations. According to them the BK 81, BK 81-S Knife Sharpening Machine is brought all relevant, basic safety and health requirements.

NEWROX

Because, by definition, the BK 81, BK 81-S Knife Sharpening Machine is a machine (Chapter I, Article 1, Sect. 2 (a) Machinery Directive), the operating instructions are based on the

Machinery Directive 2006/42/EG

Prior to placing it on the market, the Knife Sharpening Machine has been subjected *inter alia* to a risk assessment on the basis of EN 1050. The residual risk from the risk assessment was taken into account in the form of safety and conduct instructions.

To confirm conformity of the BK 81, BK 81-S Knife Sharpening Machine, Newrox AG has issued a

declaration of conformity according to the Machinery Directive,

to which a copy of the Operating Instructions is attached; the Operating Instructions thus become an integral part of placing the BK 81, BK 81-S Knife Sharpening Machine on the market. The CE mark is located on the type plate of the Knife Sharpening Machine.

Knife Sharpening Machine BK 81, BK 81-S

Version: 14.07.2021

Page 7 of 39

1.2 Declaration of conformity

Newrox AG CH - 4147 Aesch / Switzerland

EG Declaration of Conformity

in accordance with Directive 2006/42/EG

Directive 2006/42/EG applies to this product.

We declare herewith on our sole responsibility that we satisfy the obligations of Directive 2006/42/EG and that the products comply with the requirements of the directive.

In the event of any change to the product not approved by us, this declaration looses its validity.

Product designation: Type: Year of manufacture: Serial Numbers: Knife Sharpening Machine BK 81+BK 81-S Placed on the market by: Newrox AG Hauptstr. 105 CH-4147 Aesch

NEWROX

Authorised agent of EU: Paul Schöndorf Metallwaren GmbH Am Untergrün 4 D-79232 March Buchheim

Further applicable Directive: EMV Directive 2004/108/EG

Standards used	: EN 12100	Status 08.2013
	EN 13854	Status 01.2020
	EN 60204-1	Status 06.2019
	EN 14118	Status 07.2018

Aesch, 14. Juli 2021

(Signature Ceo)

Newrox AG

Knife Sharpening Machine BK 81, BK 81-S

Version: 14.07.2021

Page 8 of 39

NEWROX

2.0 Scope of supply

- 1) Sharpening machine
- 2) Operating Instructions with Brief Instructions
- 3) Mains cable
- 4) Polishing paste
- 5) Oilstone
- 6) Hexagon key, 2.5 mm
- 7) Hexagon key, 6 mm
- 8) Ring spanner 10-13 mm

Supplemental cope of supply by version S

- 1) 2 support bracket for scissors
- 2) Attachment screw

2.1 Accessories

1) Work benchOrder No.: SM-10202) Dust extractorOrder No.: SM-1010

Knife Sharpening Machine BK 81, BK 81-S

Version: 14.07.2021

Page 9 of 39

3.0 Safety instructions before commissioning



Only put the Knife Sharpening Machine into operation when it has been correctly connected, and the user is thoroughly aware of its functions and of potential hazards Commissioning shall only be carried out by an authorised, instructed specialist appointed by the operating authority.

NEWROX

Further procedures and measures

- 1) Check the scope of supply for transport damage and, where appropriate, take steps to repair or replace damaged parts.
- Check that the Operating Instructions are present and complete. Do not use the machine without the Operating Instructions. The Operating Instructions must be available at the machine.
- The Brief Instructions supplied are intended for use at the machine. They are not intended to replace the Operating Instructions. The Operating Instructions must still be read and observed.
- 4) Check functions on the basis of the Operating Instructions.
- 5) When the machine is handed over to the user, it is essential that he or she is instructed on the basis of the Operating Instructions.
- 6) Recommissioning after maintenance work:



Before recommissioning, the user or the repair personnel must make sure that the Knife Sharpening Machine can be correctly returned to service in accordance with the Operating Instructions.

In particular the electrical connection must comply with connection data, and the grinding wheel must rotate in the specified direction.

Knife Sharpening Machine BK 81, BK 81-S

Version: 14.07.2021

Page 10 of 39

3.1 Safety concept

The hazard points and the risks arising from them have been assessed in a risk analysis. The residual risks are described below in these Operating Instructions with explanations and recommendations how they can be avoided by the operating authority and the user.

NEWROX

Residual hazards and risks can never be entirely excluded due to potential malicious or improper use. The residual risk arising from the Knife Sharpening Machine is reduced by warning labels on the machine calling *inter alia* for the user to wear protective goggles, and by recommendations in the Operating Instructions.

There is always a possibility of components failing due to defects in materials or inadequate strength. For the Knife Sharpening Machine, no recognisable danger for the user or repairer would arise from such causes.

Decisive for the protection of the user and third parties is the safety-optimised design and construction, and modern safety concept for the grinding and polishing processes.

The machine has the following safety features:

- 1) The grinding wheel rotates towards the cutting edge so that neither the knife nor limbs can be drawn in.
- 2) There are very small clearances between the guard and the polishing disc to prevent limbs being drawn in.
- 3) Short run-down times for the discs.
- 4) Foodstuffs hygiene is possible and sustainable because a non-porous grinding wheel (metal not ceramic) is used.

3.2 What to do in the event of an accident

- 1) Switch the machine off
- 2) Call for first-aid assistance and have wounds dressed
- 3) Inform your supervisor
- 4) Describe how the accident happened (accident log)
- 5) Inform Newrox AG about the hazard

Knife Sharpening Machine BK 81, BK 81-S

NEWROX

Version: 14.07.2021

Page 11 of 39

3.3 Hazard points and types of hazard

The risk assessment for the BK 81, BK 81-S Knife Sharpening Machine found the following hazard points related to the grinding and polishing processes.

Figure showing hazard points



Fig. 1

Dangers and residual risks at hazard points during operation

Hazard point 1

The greatest danger is that through an operating error (knife blade is placed the wrong way round against the grinding wheel) the wheel will grab the knife and pieces will break off and be ejected. For this reason a guard and a knife support are incorporated. In addition, there is an arrow label to show the correct direction of rotation. To minimise the remaining residual risk, a further label on the machine and a symbol in the Operating Instructions instruct the user to wear protective goggles.

The likelihood of body parts being caught up, drawn in, crushed or abraded is very low due to the protective measures adopted, and so presents a very small danger.

Knife Sharpening Machine BK 81, BK 81-S

Version: 14.07.2021

Page 12 of 39

Hazard point 2

The likelihood of body parts being caught up, drawn in, crushed or abraded is very low due to the protective measures adopted, and so presents a very small danger. To protect against ejected particles (dust), we recommend that dust extraction is used, and the user is instructed to wear protective goggles.

NEWROX

Consideration of general hazards

User

For the user the residual risks are relatively low, because hazard points that result from process motions are avoided by the safety concept described above.

Maintenance and repair personnel

Maintenance and repair personnel are far more exposed, because they must work on the machine when it is open and protective equipment switched off.

The machine can be operated by a third party. The machine can also be operated by Maintenance or repair personnel. Therefore:



Caution!

Risk of trapping and crushing injuries to fingers from rotating discs

> Do not touch or grasp rotating discs



Caution!

Danger from electric voltage > Before opening the housing disconnect the mains plug!

For maintenance and repair personnel, appropriate measures must be taken to avoid hazards, for example, by means of a clear instruction to disconnect from the mains before opening the machine. In principle, all hazards that apply to the user could also affect maintenance and repair personnel.

Knife Sharpening Machine BK 81, BK 81-S

Version: 14.07.2021

Page 13 of 39

Other hazards

Other dangers arise from electrical energy – protective measures:

Besides the above hazards, fundamentally the danger of electric shock can arise from any machine operated by electric power as a result of the failure protection systems or wear.

NEWROX

Here, protective measures are correct operation, repeated inspection of the equipment to ensure that type-related requirements remain fulfilled, regular maintenance and repair, and the notification and rectification of faults and damage.



Caution!

Hazards due to dust The small amount of abraded material can be removed by connecting a dust extractor.

INSTRUCTION

If a dust extractor is not connected, wear a dust-protection mask. In Germany the operating authority must ensure that the work safety regulations and the instructions and regulations of the Berufsgenossenschaft (BGR), and in Switzerland those of the Schweizerischen Versicherungsanstalt (SUVA) are strictly observed. Similarly, if the machine is used in another country, the relevant work safety regulations there must be observed. In addition, suitable personal protective equipment (PPE), for example ear defenders, protective goggles, and dust-protection masks must be available; such equipment must also comply with relevant EU directives.

Knife Sharpening Machine BK 81, BK 81-S

Version: 14.07.2021

Page 14 of 39

3.4 Intended use

Section 4.0 defines "Requirements of the operating personnel" and provides useful information to aid their selection. A substantial part of proper use and avoiding incorrect use is already covered there. In the construction of the machine, it is assumed that the machine will be used for the intended purpose. This has led the designer to construct the machine so that improper use is prevented or at least very difficult.

NEWROX

The BK 81, BK 81-S Knife Sharpening Machine has been designed and constructed for grinding knives in catering operations, in meat and foodstuffs processing, and for sharpening-service providers.

It is only suitable for use as a stationary, bench-mounted unit.

- 1) The BK 81, BK 81-S Knife Sharpening Machine is intended exclusively for commercial use.
- 2) The BK 81, BK 81-S Knife Sharpening Machine is suitable for steel-bladed knives with hardness in the 50 65 HRC range.
- 3) The BK 81, BK 81-S Knife Sharpening Machine may only be used when it is in perfect technical condition (see Section 5.0, Technical Data).
- 4) When installing and commissioning the machine, the ambient conditions must be observed, in particular with regard to electrical safety (degree of protection, protection class, connection to the mains).
- 5) The machine must always be switched of after use
- 6) In the event of faults in the power supply and/or damage to the electrical or mechanical equipment, the BK 81, BK 81-S Knife Sharpening Machine must be switched off immediately and the main switch secured against uncontrolled switching back on.
- 7) Any faults or damage found must be corrected without delay.
- 8) The connection data, conditions for use, and performance data defined under proper use may not be changed.
- 9) The BK 81, BK 81-S Knife Sharpening Machine may not be modified or otherwise changed without prior consultation with and written approval from Newrox AG.
- 10) The protective equipment installed by Newrox AG must except when expedient for maintenance or repair – always be present, correctly installed and fully functional. Protective equipment must never be circumvented of rendered ineffective.
- 11) Safety components such as limit switches, valves and other control system components may not be rendered non-functional.
- 12) The operating authority and the user must take suitable measures to forbid or prevent uncontrolled access to the immediate vicinity of the BK 81, BK 81-S Knife Sharpening Machine (even when it is out of service).
- 13) Persons who are under the influence of alcohol, other drugs or medications which impair their reactions may not use, repair or maintain the BK 81, BK 81-S Knife Sharpening Machine.

Knife Sharpening Machine BK 81, BK 81-S

Version: 14.07.2021

Page 15 of 39

3.5 Improper use

Axes, scissors and related objects may not be ground on this machine! Scissors only with version "S". The machine is not suitable for knives with a serrated edge!

NEWROX

Accidents can only be avoided and trouble-free operation of the BK 81, BK 81-S Knife Sharpening Machine ensured if these Operating Instructions are strictly observed by the operating authority and the user.

Observing the Operating Instructions:

- 1) reduces downtime and repair costs
- 2) extends the useful life of the BK 81, BK 81-S Knife Sharpening Machine
- 3) ensures safe, ecologically sound operation

The Operating Instructions must be kept in a known location in the vicinity of the machine so that they are accessible to the user at all times.

The Operating Instructions must be read, understood and observed in all points both by the personnel responsible for the machine and by those using it.

Knife Sharpening Machine BK 81, BK 81-S

Version: 14.07.2021

Page 16 of 39

4.0 Requirements of the operating personnel

This product is intended exclusively for commercial use.

Users or operating personnel should be persons who, on the basis of their specialist training, knowledge and experience, their knowledge of relevant national legal regulations, and of the Operating Instructions are able to:

NEWROX

- 1) assess the work with which they have been entrusted,
- 2) carry it out safely,
- 3) recognise potential hazards,
- 4) and take the measures necessary to eliminate the accident potential associated with operation.

Minimum age

Persons under the age of 18 who are under instruction, undergoing training, or under supervision are not permitted to carry out any work on the Knife Sharpening Machine. This does not apply to youths who are at least 16 years old if:

- 1) it is necessary for them to operate the Knife Sharpening Machine in order to achieve a training objective;
- 2) the protection of such youths is assured by the presence of an experienced specialist;
- 3) and the work equipment, tools and protective equipment used exclude the possibility of injury.

Training

The operating authority must train users and operating personnel regularly in the following subjects:

- 1) Observance and use of the Operating Instructions and legal requirements,
- 2) Proper use of the Knife Sharpening Machine,
- 3) Yearly instruction in occupational safety and accident prevention,
- 4) Behaviour in an emergency, and safety and hazard warnings for users and operators.

Knife Sharpening Machine BK 81, BK 81-S

Version: 14.07.2021

Page 17 of 39

NEWROX

5.0 Technical data for the BK 81

Designation	Knife Sharpening Machin	e		
Туре	BK 81, BK 81-S			
Serial number				
Year of manufacture				
Machine type	Bench-mounted unit with and a separate polishing	electric motor drive for a grinding head disc.		
Associated secondary production processes	Motor, sheet-metal work, metal machining, electrical system for drive and controls, polishing disc manufacture			
Processing time	Depends on the type of grinding operation to be carried out on the knife or similar object and the composition of the blade material			
Operating personnel	One person suitably trained and instructed on the Knife Sharpening Machine, where appropriate with reference to BG guidelines or SUVA rules			
	Motor connection	230 V, 250 VA		
	Degree of protection	IP 20		
	Protection class	1		
Protective equipment	Guard for the grinding wh equipment	eel, housing, electrical protective		
External dimensions	Length 310 mm, width 360 mm, height 245 mm			
Total weight ready for use	13 kg			
Noise level	A-weighted equivalent continuous sound pressure level: <80 dB(A Noise level at workplace: <80 dB(A)			
Control system	ON-OFF switch			

Knife Sharpening Machine BK 81, BK 81-S

Version: 14.07.2021

Page 18 of 39

6.0 Description and function of the BK 81, BK 81-S Knife Sharpening Machine

The Knife Sharpening Machine is a metal-cutting machine designed to bring handheld knives in foodstuffs processing or sharpening services to optimum sharpness. The machine and its grinding unit (grinding wheel) are designed to ensure uniform grinding results under different types of use and handling.

NEWROX

The prerequisite is that the knives, due to the process used in their manufacture and their material, are suitable to provide optimum results in the Knife Sharpening Machine. This presupposes that the operator has been suitably instructed, and that the unit is in perfect working order.

6.1 Description of the machine

Grinding and polishing discs are driven by a motor with two shaft ends. The polishing disc is mounted directly on the right-hand shaft end. The grinding wheel is driven by a timing belt from the left-hand shaft end. Both discs rotate in the same direction.

Operation of the Knife Sharpening Machine is explained in detail in Section 10 of these Operating Instructions.

A drawing in Section 12.7 shows an exploded view of the machine with its individual components numbered. A table on the page following the drawing lists the parts against their numbers as shown in the drawing. There is a wiring diagram on the page after that.

6.2 Purpose of the machine

Two operations can be carried out using the Knife Sharpening Machine:

- 1) Grinding the knife is drawn between the grinding wheel and the rest, alternately from the left and the right until a grinding burr is formed.
- 2) Polishing afterwards the burr on the cutting edge caused by grinding is polished away.

Knife Sharpening Machine BK 81, BK 81-S

Version: 14.07.2021

Page 19 of 39

7.0 Transport

For transport and loading no special conditions have to be fulfilled. The packing, loading and load-securing measures that are normal for goods of this type apply.

NEWROX

The Knife Sharpening Machine and its parts are packed by Newrox AG so that in normal transport by road, rail or air freight no damage can occur that is likely to cause an undetectable safety risk during unloading, installation or operation. Should, however, damage occur during transport, this is the responsibility of the transport company, which must provide evidence of appropriate insurance and approval to Newrox AG or the operating authority.

It is a precondition that all vehicles and equipment within the transport chain comply with current work safety and accident-prevention regulations, and that the persons involved have the necessary technical qualifications and competence.

INSTRUCTION

Following transport of the Knife Sharpening Machine or its components and subassemblies, it is essential that, before the machine is installed, an inspection for transport damage is carried out to determine whether the machine and parts are defect free for subsequent operation.

Knife Sharpening Machine BK 81, BK 81-S

NEWROX

Version: 14.07.2021

Page 20 of 39

8.0 Installation and initial commissioning

Installation and initial commissioning of the Knife Sharpening Machine are carried out by the purchaser or operating authority. The operating authority must ensure that the operating personnel is instructed in all aspects of its use.

These actions must be carried out in accordance with the Operating Instructions. The components and sub-assemblies of the Knife Sharpening Machine do not give rise to any hazard, e.g. from auxiliary materials.

The general work safety and accident-prevention regulations for the country in which the machine is installed apply.

8.1 Requirements of the installation location

The machine is only suitable for use in dry rooms in the temperature range from +10 to +30 degrees Celsius.

The Knife Sharpening Machine is a bench-mounted unit which requires a mounting sufficiently stable for its weight and use.

The mounting surface must be flat and horizontal. In particular, it must be in a room that permits safe operation of the Knife Sharpening Machine.

8.2 Cleaning after installation

INSTRUCTION Keep the machine and its surroundings clean!

Knife Sharpening Machine BK 81, BK 81-S

NEWROX

Version: 14.07.2021

Page 21 of 39

9.0 Assembly and commissioning

This section indicates the main work steps that it is important for the operator to follow in order to ensure danger-free switching on and off, grinding and polishing.



In the event of a fault or a warning, the person responsible for the Knife Sharpening Machine must always be notified. Correction of a fault by the Operator or a person not authorised to do so is a potential danger to the operator and third parties.

The machine is supplied assembled and ready to use.

- 1) Remove the machine from its packing.
- 2) Check that it is complete see Section 2.0, Scope of supply.
- 3) Connect the mains lead

9.1 Control elements

The ON-OFF switch is on the left side of the machine.

Press the green button: ON Press the red button: OFF

The dust extractor (available as an accessory) is switched on and off with the machine. For it to operate, its plug must be connected to the appropriate socket, and the dust extractor tube to the nozzle on the machine.





Knife Sharpening Machine BK 81, BK 81-S

NEWROX

Version: 14.07.2021

Page 22 of 39

10.0 Handling

The Operating Instructions must be used to ensure proper use of the Knife Sharpening Machine and to recognise faults. The Brief Instructions supplied are intended for use at the machine. They are not intended to replace the Operating Instructions. The Operating Instructions must still be read and observed.

10.1 Grinding and polishing procedure



Wear protective goggles!



Caution!

Do not use the machine to sharpen axes, hatchets, wavy-edged knives etc. This machine is only suitable for meat knives, kitchen knives etc. that do not have grooves or a wavy edge. Excessive pressure on the grinding wheel will cause blueing of the knife.

- 1) Stand in front of the machine.
- 2) Start with the handle as close as possible to the grinding wheel.
- 3) Without pressure, draw the handle to the right, away from the grinding wheel.
- 4) The blade should contact the grinding wheel in the middle of its width. Raise the handle progressively as you move the knife so as to give the blade the required form. Important! The blade must not become discoloured.



Fig. 3

Knife Sharpening Machine BK 81, BK 81-S

NEWROX

Version: 14.07.2021

Page 23 of 39

5) Allow the tip of the knife to grind out with the grinding wheel in the middle of the blade width (do not draw the knife beyond the grinding wheel).



Fig. 4

- 6) You can grind just the tip of the knife it is not always necessary to grind the whole blade.
- 7) Repeat the whole procedure for the other side of the knife. This time the knife handle must be to the left of the grinding wheel.



Fig. 5

Important! Repeat the grinding operations until there is a fine grinding burr all the way along the cutting edge. Next, the blade must be polished.

8) Apply abrasive paste to the polishing disc.





Knife Sharpening Machine BK 81, BK 81-S

Version: 14.07.2021

Page 24 of 39



Caution!

Fire hazard from guard or knife rest contacting rotating grinding wheel or polishing disc

NEWR

> Adjust guard and knife rest so that the grinding wheel or polishing disc runs freely



Caution!

Danger of knife "catching" due to an operating error! > Never place the knife blade the wrong way round against the polishing disc!

9) Polish the blade on both sides, working horizontally from the middle of the ground zone, until the grinding burr has been removed.







10) Before using the knife again, clean off particles of grinding dust and polishing paste.

Knife Sharpening Machine BK 81, BK 81-S

NEWROX

Version: 14.07.2021

Page 25 of 39

Grinding procedure of scissors (only possible with BK 81-S)

Only for household-, handycraft-, paper-, carpet- and dressmaker scissors without spike or mikrospike! **Only for top side grinding of scissor.** Not for innerface or spike grinding.

1) Replace the scissors stop!



Fig. 9

- 2) Unscrew scissor or, when it is not possible, swing open.
- 3) If necessary: Clean, derust, whetting inner face.





Knife Sharpening Machine BK 81, BK 81-S

Version: 14.07.2021

Page 26 of 39

NEWROX

- 4) Grinding top side. Put scissor with innerface on bearing area.
- 5) Begin grinding from the handle, without pressure.



Fig. 11

6) Draw scissor to the right. Control grinding pattern. Repeat the operation until there is a fine grinding burr all the way along the cutting edge.



Fig. 12

- 7) Drawing off the burr with an oelstone.
- 8) Clean scissor, oil, replace and adjust it. Controll the tips to overlap. Otherwise trim the tips until there overlap.

Knife Sharpening Machine BK 81, BK 81-S

NEWROX

Version: 14.07.2021

Page 27 of 39

10.2 Instructions for use

For the operator of the Knife Sharpening Machine, the operating authority must write work instructions and hang them up or otherwise make them available at the place where the machine is installed/used.

11.0 Faults and fault rectification

INSTRUCTION

In the event of a fault, danger for the operator only arises if he or she acts contrary to the Operating Instructions, for example, makes an unauthorised intervention and tries to correct the fault himself (herself).

The rectification of faults is to be carried out exclusively by persons authorised to do so by the operating authority, or by NEWROX Service.

Fault	Possible cause	Remedy
Machine does not run	 No power Build up of dirt in the machine due to poor maintenance 	- Check mains connection Attention! Observe safety instructions - Disconnect the mains plug!
		Clean the machine as described in Section 12.4
	- Timing belt broken	Check as follows: - Disconnect the mains plug! - Turn the polishing disc with your finger (if the grinding wheel does not turn as well, the timing belt is broken or has jumped its pulleys. Contact the supplier and have the belt replaced.)
Machine vibrates severely	- Polishing disc is out of balance, e.g. due to moisture	Attention! Observe safety instructions - Disconnect the mains plug! - Change polishing disc as described in Section 12.5.
Knives not being properly sharpened	- User error - Grinding wheel worn out	 Contact the supplier Attention! Observe safety instructions Disconnect the mains plug! Change grinding wheel as described in Section 12.5.

Knife Sharpening Machine BK 81, BK 81-S

NEWROX

Version: 14.07.2021

Page 28 of 39

12.0 Maintenance, repairs, cleaning and care

The term "corrective maintenance" describes all measures aimed at conserving and reinstating the proper condition, and to determining and assessing the current state of the technical means of a system or the system itself.

The above measures are sub-divided into:

Inspection (determining the current state)

E.g. checking compliance with occupational safety and accident-prevention regulations, checking settings or reference values.

Maintenance (conservation of the intended condition)

E.g. cleaning, replacing auxiliary materials and substances, replacing small wear parts (seals), retightening loose parts.

Repair work (reinstating the intended condition).

E.g. repairs following faults, failures or damage, or replacement of parts subject to wear. After repair work, a functional test must be carried out and documented in a report.

The operating authority must keep a logbook describing all maintenance and repair work. The inspections called for by occupational safety and accident-prevention regulations are to be documented by filing the relevant inspection reports. This calls for accessible files containing the relevant, up-to-date technical rules and regulations.

The logbook must contain the contents specified above and be kept up to date.

12.1 Maintenance personnel (qualification and authorisation)

We recommend that repairs and corrective maintenance are carried out by persons authorised by Newrox.

We accept no responsibility for unauthorised maintenance personnel that do not come from Newrox AG.

12.2 Safety instructions for repair work

In order to avoid danger for maintenance personnel and third parties, the hazards mentioned in Section 3.3, arising from the various measures necessary for repairs and corrective maintenance, must be taken into account. In addition, the instructions and work instructions given in Section 12.3 must be followed.

Knife Sharpening Machine BK 81, BK 81-S

NEWROX

Version: 14.07.2021

Page 29 of 39

12.3 Instructions and work instructions

- 1) All repair and corrective maintenance work must be carried out in good time, properly and completely.
- 2) Before starting repair and corrective maintenance work, inform the user of the Knife Sharpening Machine and the safety officer appointed by the operating authority. Third parties who could come into the effective area of the Knife Sharpening Machine should also be informed.
- 3) Secure the maintenance area, before starting repairs and corrective maintenance, in accordance with the occupational safety and accident-prevention regulations.
- 4) When you switch the Knife Sharpening Machine off, secure the main switch against unintentional or negligent switching back on.
- 5) Ensure that there are only authorised persons in the working area.
- 6) For exchange/replacement use only new, identical and tested components, spare parts and operating materials in original-equipment quality as listed in Newrox AG Technical Documentation. The installation of used or untested components is forbidden for safety reasons.
- 7) Every time before you (re)commission the machine, make sure that all protective devices are properly installed and have been tested to ensure that they function correctly.
- 8) Inform affected personnel from the operating authority before recommissioning the Knife Sharpening Machine.

12.4 Cleaning and care

Cleaning and care may only be carried out by persons authorised to do so by the operating authority.



Disconnect the mains plug!



Forbidden! Do not wash the machine with a water spray or jet!

After about 20 hours operation, the interior of the machine must be cleaned to remove grinding debris. To clean the grinding machine, remove the screws holding the housing cover. Use a vacuum cleaner to remove grinding debris, then replace the cover (take care not to pinch the cable) and tighten the cover screws. Take care not to over tighten the screws. To clean the outside of the housing, use a pH-neutral cleaning agent.

After cleaning and care with a liquid, do not put the machine back into operation immediately – allow the unit to dry after cleaning, or use dry cloths to wipe it dry.

Knife Sharpening Machine BK 81, BK 81-S

Version: 14.07.2021

Page 30 of 39

12.5 Instructions for changing grinding wheels and polishing discs

Grinding wheels and polishing discs may only be changed by Newrox Service or persons authorised to do so by the operating authority.

NEWROX

Use only original grinding wheels, polishing discs and abrasive paste, otherwise the quality of the results cannot be guaranteed. The grade of the grinding wheel, the polishing disc and the abrasive paste are precisely adapted to each other.

Changing the **grinding wheel** (see drawing in Section 12.9)



Disconnect the mains plug!

- 1) Undo the four screws, Pos. 157, holding the cover, Pos.14
- 2) Remove the cover and place it on the left beside the machine
- 3) Take care that the cable connections are not disturbed
- 4) Hold the shaft, Pos. 012, with a 19 mm open-ended spanner in the middle and undo the nut Pos. 160
- 5) Remove the grinding wheel, Pos. 13, and replace it with a new one
- 6) Use the new self-locking nut supplied, Pos.160, to secure it, Tightening torque: 35 Nm
- 7) Replace the cover take care of the cable connections
 - fit the four screws and tighten them gently
- 8) Check that the grinding wheel and polishing disc turn freely without rubbing on the housing

Changing the **polishing disc** (see drawing in Section 12.9)



Disconnect the mains plug!

- 1) Undo the four screws, Pos. 157, holding the cover, Pos.14
- 2) Remove the cover and place it on the left beside the machine
- 3) Take care that the cable connections are not disturbed
- 4) Undo the screw, Pos.159 (left-hand thread), while holding the polishing disc, Pos.107, with the other hand
- 5) Remove the screw, Pos.159
- 6) Remove washers, Pos.169 and 161, and clamping disc, Pos. 008, remove the polishing disc, Pos. 107, and replace it with a new one
- 7) Replace the clamping disc and washers, and tighten the screw, Pos.159
- 8) Replace the cover taking care of the cable connections, then fit the four screws and tighten them **gently**
- 9) Check that the grinding wheel and polishing disc turn freely without rubbing on the housing

Knife Sharpening Machine BK 81, BK 81-S

Version: 14.07.2021

Page 31 of 39

12.6 **Preventive maintenance and repair plan**

Task	How often	Material, procedure
Clean interior	Every 20 hours operation	See Section 12.4, Cleaning and care
Change polishing disc	When worn to \emptyset 165 mm	See Section 12.5, Changing the polishing disc
Change grinding wheel	Every 10,000 grinding operations	See Section 12.5, Changing the grinding wheel
Maintenance and change timing belt	Every 5 years	Contact the supplier

NEWROX

12.7 Testing

The Knife Sharpening Machine must be tested every time before commissioning or recommissioning, e.g. after repair work, to ensure the safety devices function and that the machine operates correctly. Similarly, a regular test (generally once a year) is to be carried out. Use the test report, below, for these tests.

Knife Sharpening Machine BK 81, BK 81-S

Version: 14.07.2021

Page 32 of 39

NEWROX

Test Report for BK 81.E	3K 81-S Knife Sha	rpening Machir	ne			
Reason for test: Regular First time / Before recommissioning						
Scope of test: Usual and functional test Other						
Type of machine:		Ma	nufacturer: Year o	f manufacture:	Туре:	
Machine No.:0	Operating hours: _	Electr	ical connection:	Location:		
Test items (in the even	t of a defect, mark	the test item w	vith a cross and de	scribe the defect in	the box, below)	
Documentation:	Test log	Operating	/ assembly instruct	tions 🛛 Works log	J	
Markings:	□ Labels	□ Hazard po	int markings			
Labels:	Warning labels	s \Box Direction a	irrows	□ CE marking		
Components and	□ Installation	□ Supports	□ Power supply	□ Covers		
equipment	Electrical	🗆 Manual	□ Drive	□ Other		
	(e.g. mains and i	solation switch	, safety switch, sw	itch lock,		
	limit switch, drive	e, main switch)				
Control items:	Overload fuses,	control system	is, regulation, mea	surement devices		
	🗆 Leads 🛛 Driv	ve / consumers	B Display / S	signals		
	□ Control eleme	nts				
	□ Illumination of	workplace	□ Insulation	/ contact protection	1	
	□ Power failure		□ Other			
Safety distances	□ Safety distanc	es 🗆	Crushing and shea	aring points		
Access	□ Access / work	ing posture 🗆	Other			
Other items:	External condition	ition 🗆 🗆	Working and auxili	ary substances	□ Sound / Noise	
	□ Emissions		Maintenance / Insp	pection	□ First aid	
	□ State of tooling	g (grinding whe	eel, polishing disc)			
Result of test						
Minor defects:	(correction at nex	xt maintenance	2)			
Substantial defects:	(correction of def	fects before ne	xt use)			
Dangerous defects:	(it is recommend	ed that the unit	t is temporarily take	en out of use)		
Overall result:	Test object hat	s no defects		has defects		
Description of defects:						
Retesting	□ Yes □ No	1	Sticker applie	d □ Yes	□ No	
Test date:			Next test:			
Inspector: Name		Sig	nature:			

Knife Sharpening Machine BK 81, BK 81-S

NEWROX


Version: 14.07.2021

Page 33 of 39

12.8 Maintenance and repair procedure

The maintenance and repair procedure for the Knife Sharpening Machine depends on consistent, regular testing of the items given in Sections 12.6 + 12.7.

Procedure diagram for maintenance and repair work



Knife Sharpening Machine BK 81, BK 81-S

Version: 14.07.2021

Page 34 of 39

NEWROX

12.9 Drawings and plans Parts and spare parts list

Pos.	Description	Quantity	Order number
1	Baseplate	1	8101
2	Motor rail	2	8102
3	Bearing housing	1	8103
4	Base stop	1	8104
252	Rest head 0°, 5°, 10°	1	81252
6	Sliding plate, spring plate	1	8106
7	Extraction nozzle	1	8107
8	Clamping disc	2	8108
9	Spacer	1	8109
10	Dust protection plate	1	8110
11	Dust guide plate	1	8111
12	Shaft	1	8112
13	Grinding wheel	1	8113
14	Cover	1	8114
15	Protection plate, polishing disc	1	8115
16	Knife rest	1	8116
17	Spacer tube	2	8117
18	Earthing shoe	1	8118
50	Electric motor EBSR 63K2	1	8150
51	Button	1	8151
52	Connector block Type 0712	1	8152
53	Relay	1	8153
54	Capacitor	1	8154
100	Buffer	4	81100
101	Buffer washer	4	81101
103	Ball bearing	2	81103
104	Timing belt pulley Z20	1	81104
105	Timing belt pulley Z25	1	81105
106	Timing belt	1	81106
107	Polishing disc	1	81107
108	Cable sleeve	1	81108
109	Rubber section	1	81109
4=-			
150	Socket cap screw	4	81150
151	Socket cap screw	1	81151
152	Hex. hd. screw	4	81152
153	Hex. hd. screw	1	81153
154	Socket cap screw	4	81154
155	Countersunk screw	4	81155
156	Hex. hd. screw	4	81156
157	Raised csk. screw	15	81157

Knife Sharpening Machine BK 81, BK 81-S

Version: 14.07.2021

Page 35 of 39

NEWROX

Pos.	Description	Quantity	Order number
158	Hex. hd. screw	1	81158
159	Hex. hd. screw	1	81159
160	Hex. nut, self-locking	2	81160
161	Washer	2	81161
162	Washer	4	81162
163	Washer	4	81163
164	Serrated washer	8	81164
165	Acorn nut	2	81165
166	Parallel key	1	81166
167	Serrated washer	4	81167
168	Toothed washer	1	81168
169	Serrated washer	2	81169
170	Spring washer	1	81170
171	Washer	1	81171
200	Label, Newrox BK 81"	2	81200
201	Label "Wear protective goggles"	1	81201
202	Label "Disconnect mains plug"	1	81202
203	Type plate	1	81203
204	Label "Caution electric voltage"	1	81204
205	Label "Direction arrow"	2	81205
206	Earth label	2	81206
250	Polishing paste	1	81250
251	Oilstone	1	81251
253	Mains cable	1	81253
254	Hexagon key 2,5	1	81254
255	Hexagon key 6	1	81255
256	Ring spanner 10-13		81256
301	Scissors stop 85°- only for Version "S"	1	81S05
302	Scissors stop 75°- only for Version "S"	1	81S06


Knife Sharpening Machine BK 81, BK 81-S

Version: 14.07.2021

Page 36 of 39

NEWROX

Exploded drawing



Knife Sharpening Machine BK 81, BK 81-S

Version: 14.07.2021

Page 37 of 39

NEWROX

Parts list for exploded drawing


Pos.	Description	Pos.	Description
1	Baseplate	150	Socket cap screw
2	Motor rail		Socket cap screw
3	Bearing housing	152	Hex. hd. screw
4	Base stop	153	Hex. hd. screw
252	Tilting head stop 0°, 5°, 10°	154	Socket cap screw
6	Sliding plate, spring plate	155	Countersunk screw
7	Extraction nozzle	156	Hex. hd. screw
	Clamping disc		Raised csk. screw
9	Spacer	158	Hex. hd. screw
10	Dust protection plate	159	Hex. hd. screw
	Dust guide plate		Hex. nut, self-locking
12	Shaft	161	Washer
	Grinding wheel		Washer
	Cover complete		Washer
15	Protection plate, polishing disc		Serrated washer
16	Knife rest	165	Acorn nut
17	Spacer tube		Parallel key
18	Earthing shoe	167	Serrated washer
			Toothed washer
	Electric motor EBSR 63K2		Serrated washer
	Button		Spring washer
	Connector block Type 0712		Washer
	Relay		Label, Newrox BK 81"
54	Capacitor		Label "Wear protective goggles"
			Label "Disconnect mains plug"
	Buffer		Type plate
101	Buffer washer		Label "Caution electric voltage"
		205	Earth label
	Ball bearing		
	Timing belt pulley Z20	301	Scissors stop 85°- only for Version "S"
	Timing belt pulley Z25	302	Scissors stop 75°- only for Version "S"
	Timing belt		
	Polishing disc		
	Cable sleeve		
109	Rubber section		


Knife Sharpening Machine BK 81, BK 81-S

Version: 14.07.2021

Page 38 of 39

NEWROX





Knife Sharpening Machine BK 81, BK 81-S



Version: 14.07.2021

Page 39 of 39

13.0 Instructions for disposal

When disposing of the machine, observe local legal requirements. The machine contains no hazardous substances (possible exception: materials that may be incorporated in electrical components)

14.0 List of drawings and diagrams supplied

Parts and spare parts list	Pages 34+35
Exploded drawing	Page 36
Parts list for exploded drawing	Page 37
Wiring diagram	Page 38

15.0 Index of illustrations

Fig. 1	Hazard points	Page 11
Fig. 2	Control elements	Page 21
Fig. 3	Polishing procedure	Page 22
Fig. 4	Polishing procedure	Page 23
Fig. 5	Polishing procedure	Page 23
Fig. 6	Polishing procedure	Page 23
Fig. 7	Polishing procedure	Page 24
Fig. 8	Polishing procedure	Page 24
Fig. 9	Scissor procedure	Page 25
Fig. 10	Scissor procedure	Page 25
Fig. 11	Scissor procedure	Page 26
Fig. 12	Scissor procedure	Page 26

16.0 Copyright

These Operating Instructions may not be electronically or mechanically reproduced, distributed, changed, transmitted, translated into another language, or otherwise used or reproduced either in whole or in part without express written approval from Newrox AG. If, however, by using copies or partial copies, the safety of users, operators, or third parties at the BK 81 Knife Sharpening Machine can be assured during its proper use, then such copies are exceptions and independent of copyright.